

Datasheet

REF: 407 570
Universal databand clip adaptor

Used to fix a postcard holder in a databand rail. It Fits the 2 rectangular holes in the back of the postcards holder.

